


Remove LH insulator. Locate and tap wire from connector terminal shown. Connect new wire to KeeSmart option terminal "E"

IGNITION KEY WARNING, CIRCUIT #80



CONNECTOR "C202"
(Base of steering column)

'87-'93 "KEY IN" OPTION CONNECTION